

INSERTION LOSS

When considering RF attenuators, it is important to underline the difference between "attenuation" and "insertion loss".

The **insertion loss** L_I of a device is the power loss due to the insertion of the device before the load. It could be induced by a real attenuation (a loss), but also by mismatch and resulting power reflection.

The value L_I is given by the ration, in logarithmic units, between the received power in two conditions:

- 1) Direct connection between the load L and the source G,
- 2) Insertion of the device (A in figure 1) between load and source.




Figure 1

With respect to figure 1, the insertion loss L_I is defined as:

$$L_I = 10 \log \left(\frac{P_1}{P_2} \right)$$

When both load and source are matched, the insertion loss is equal to the **attenuation coefficient** α :

$$\alpha = L_I \Big|_{\Gamma_G = \Gamma_L = 0}$$

The coefficient α is due to the sum of two contributions, the reflection one α_R (due to the attenuator mismatch) and the loss one α_D . The definitions are:

$$\alpha_R = 10 \log \left(\frac{P_I}{P_I - P_R} \right)$$

$$\alpha_D = 10 \log \left(\frac{P_I - P_R}{P_L} \right)$$

$$\alpha = \alpha_R + \alpha_D$$

where P_I, P_R, P_L are respectively the incident power, the power reflected by the attenuator and the power at the load (figure 2).




Figure 2

With respect to the attenuator scattering matrix, using the definition of figure 3, the attenuation parameters are given by:

$$\alpha = 10 \log \left(\frac{P_I}{P_L} \right) = 10 \log \frac{1}{|S_{21}|^2} \quad \alpha_D = 10 \log \frac{1 - |S_{11}|^2}{|S_{21}|^2} \quad \alpha_R = 10 \log \frac{1}{1 - |S_{11}|^2}$$

because the power involved are expressed as:

$$P_I = \frac{|a_1|^2}{2}$$

$$P_L = \frac{|b_2|^2}{2}$$

$$P_R = \frac{|b_1|^2}{2}$$




Figure 3

MISMATCH ERROR

We want to evaluate the error on the insertion loss, induced by the mismatch of the attenuator ($S_{11}, S_{22} \neq 0$) and, mostly, by the mismatch of the system ($\Gamma_G, \Gamma_L \neq 0$).

First of all we calculate what happens without the attenuator (figure 4):




Figure 4

$$\begin{cases} a = e_g + \Gamma_G b \\ b = \Gamma_L a \\ P_L = \frac{|a|^2}{2} - \frac{|b|^2}{2} \end{cases}$$

By solving the equations we obtain:

$$a = e_g \frac{1}{1 - \Gamma_G \Gamma_L}$$

$$P_L = \frac{|a|^2}{2} (1 - |\Gamma_L|^2)$$

$$\Rightarrow P_{L,1} = \frac{|e_g|^2}{2} \frac{1 - |\Gamma_L|^2}{|1 - \Gamma_G \Gamma_L|^2}$$

Now we insert the attenuator and calculate the resulting power received by the load (as in figure 3). We have 4 equations: 1 at the source, 1 at the load, and 2 from the scattering matrix.

$$\begin{cases} a_1 = e_g + \Gamma_G b_1 \\ a_2 = \Gamma_L b_2 \\ b_1 = S_{11} a_1 + S_{12} a_2 \\ b_2 = S_{21} a_1 + S_{22} a_2 \\ P_L = \frac{|b_2|^2}{2} (1 - |\Gamma_L|^2) \end{cases} \Rightarrow \begin{cases} b_1 = S_{11} (e_g + \Gamma_G b_1) + S_{12} \Gamma_L b_2 \\ b_2 = S_{21} (e_g + \Gamma_G b_1) + S_{22} \Gamma_L b_2 \end{cases} \Rightarrow \begin{cases} b_1 (1 - \Gamma_G S_{11}) = S_{11} e_g + S_{12} \Gamma_L b_2 \\ b_1 (-\Gamma_G S_{21}) = S_{21} e_g + (S_{22} \Gamma_L - 1) b_2 \end{cases}$$

Lets find the value of b_2 , in order to express the load power as a function of the scattering coefficients and of the reflection coefficients:

$$\frac{S_{11}e_G + S_{12}\Gamma_L b_2}{1 - \Gamma_G S_{11}} (-\Gamma_G S_{21}) = S_{21}e_G + (S_{22}\Gamma_L - 1)b_2$$

therefore:

$$b_2 = \frac{S_{11}e_G S_{21}\Gamma_G + S_{21}e_G (1 - \Gamma_G S_{11})}{-S_{21}\Gamma_L \Gamma_G S_{12} + (1 - \Gamma_L S_{22})(1 - \Gamma_G S_{11})} = \frac{e_G S_{21}}{(1 - \Gamma_L S_{22})(1 - \Gamma_G S_{11}) - S_{12}S_{21}\Gamma_G \Gamma_L}$$

In conclusion:

$$P_{L,2} = \frac{|e_G|^2}{2} \frac{|S_{21}|^2 (1 - |\Gamma_L|^2)}{|(1 - \Gamma_L S_{22})(1 - \Gamma_G S_{11}) - S_{12}S_{21}\Gamma_L \Gamma_G|^2}$$

The insertion loss is given by the ratio of the power values in the two situations:

$$\begin{aligned} L_I &= 10 \log \frac{P_{L1}}{P_{L2}} = 10 \log \frac{|(1 - \Gamma_L S_{22})(1 - \Gamma_G S_{11}) - S_{12}S_{21}\Gamma_L \Gamma_G|^2}{|S_{21}|^2 |1 - \Gamma_G \Gamma_L|^2} = \\ &= 10 \log \frac{1}{|S_{21}|^2} + 10 \log \frac{|(1 - \Gamma_L S_{22})(1 - \Gamma_G S_{11}) - S_{12}S_{21}\Gamma_L \Gamma_G|^2}{|1 - \Gamma_G \Gamma_L|^2} \end{aligned}$$

The first term represents the attenuation coefficient, corresponding to the insertion loss when the system is matched ($\Gamma_G = \Gamma_L = 0$). We can define the **mismatch error** M as:

$$M = L_I - \alpha = 10 \log \frac{|(1 - \Gamma_L S_{22})(1 - \Gamma_G S_{11}) - S_{12}S_{21}\Gamma_L \Gamma_G|^2}{|1 - \Gamma_G \Gamma_L|^2}$$

Typically, the M coefficient is plotted as a function of the standing wave ratio of the system ($VSWR = \frac{1 + |\Gamma|}{1 - |\Gamma|}$), see figure 5, under some simplifying assumptions:

- The plot represents the maximum error (that is, we consider the phases of the complex parameters such as to maximize the error);
- The attenuator is assumed symmetric ($S_{11} \cong S_{22}$);
- The system is assumed symmetric ($\Gamma_G \cong \Gamma_L$);
- The plot is parametric with respect to the attenuator VSWR, with the assumption of loss > 20 dB.




Figure 5